





PRESETS

Presets & Functions	Texture (Hours:Minutes)			Time (Hours:Minutes)	
	Less	Normal	More	Min	Max
Rice	00:07	00:10	00:13	00:01	01:40
Multi Grain	00:22	00:27	00:32	00:01	01:40
Soup	00:10	00:15	00:20	00:01	01:40
Meat/Stew	00:20	00:40	00:50	00:01	01:40
Poultry	00:15	00:20	00:25	00:01	01:40
Beans	00:15	00:20	00:25	00:01	01:40
Fish	00:06	00:08	00:10	00:01	01:40
Steam/Veggies	00:03	00:05	00:07	00:01	01:40
Potatoes	00:04	00:06	00:10	00:01	01:40
Bake	00:30	00:40	00:50	00:01	01:40
Canning*	/	00:20	/	00:01	01:40
Delay 	/	/	/	00:05	24:00
Warm* 	/	04:00	/	01:00	24:00
Sear* 	/	00:05	/	00:01	00:20
Slow Cook* 	/	04:00	/	02:00	09:00

*Only operable in one texture mode.

- 1 Select desired preset.
- 2 Adjust texture if necessary. The default texture is normal. For instructions on changing texture see page 16.
- 3 Close Lid.
- 4 Begin by pressing the “start/stop” button.

For all Presets:

- Pressing the “-” or “+” buttons will switch to “manual” mode.
- Press “start/stop” twice to clear.
- The pressure cooker will clear in 30 seconds if the “start/stop” button is not pressed.

hours/minutes

Press the “hours/minutes” button to set the time when using the “time” function or to increase or decrease the cooking duration when cooking in “manual” mode. The blinking digits reflect whether hours or minutes are selected. Pressing the “+” and “-” buttons will increase or decrease the cooking time.

